Panasonic Broadcast Mechanical Parts List

MODEL No.: AJ-HPX2000P, AJ-HPX2100E/MC, AJ-YA350G

Note:


- 1. *Be sure to make your orders of replacement parts according to this list.
- Unless otherwise specified, all resistors are in OHMS, K=1,000 OHMS, all capacitors are in MICROFARADS (μF), P=μμF.
- The P.C.Board unit marked with "■" shown below the main assembled parts.
- 4. The parts marked with ©on the exploded view show the electric parts.
- 4. IMPORTANT SAFETY NOTICE
 - Components identified with the mark \triangle have the special characteristics for safety, When replacing any of these components, use only the sametype.
- 6. The marking (RTL) indicates the retention time is limited for this item.

 After the discontinuation of this assembly in production, it will no longer be available.
- 6. "M" in Remark column indicates needed in the periodical maintenance.

CONTENTS


CASING & FRAME PARTS ASSEMBLY OVERALL SECTION (1)(1)	MPL-1
OVERALL SECTION (2)	MPL-3
CAMERA PARTS ASSEMBLY(1)	MPL-5
CAMERA PARTS ASSEMBLY(2)	MPL-7
CAMERA PARTS ASSEMBLY(3)	MPL-7
TOP CASE & HANDLE PARTS ASSEMBLY	MPL-11
SIDE CASE (R) PARTS ASSEMBLY	MPL-13
CARD GUIDE PARTS ASSEMBLY	MPL-15
REAR JACK PARTS ASSEMBLY	MPL-17
BACK CASE PARTS ASSEMBLY	MPL-19
LCD PARTS ASSEMBLY	MPL-21
PACKING PARTS ASSEMBLY	MPL-23

CASING & FRAME PARTS ASSEMBLY OVERALL SECTION (1)




1 VYK. 2 VMP. 3 VYQ. 4 VKC 5 VJF. 6 VEE 7 VSC 8 VMP. 9 VGQ 10 VEE 11 VMT. 112 VLP. 13 K1T. 14 K1T. 102 XYN. 103 XSS 104 XTN. 105 XYN. 106 VHD 107 XSB	(K2B02 IP4853 (Q2306 (C0560 JF1158 EE1C95 SC5875 IP8764 308103 EE0286 MT0779 _P0123 ITZB9A00031 ITZB9A00052 (N26+A8FJK IN3+10JFJK (N26+J6FJ ID1774 SB3+8FJK	Part Name & Description BOTTOM CASE U LENS CONNECTOR PLATE FOOT BASE U HINGE CLAMPER LENS CABLE MIC SHEILD CASE PB GUIDE ANGLE BOTTOM PB GUIDE 2 FRONT MIC CABLE GASKET FERRITE CORE COAXIAL CABLE (BLACK) COAXIAL CABLE (RED) SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW	1 1 1 1 1 1 1 1 1 1 1 1	Remarks JOKG00000001	Ref. No.	Part No.	Part Name & Description	Pes	Remarks
1 VYK. 2 VMP. 3 VYQ. 4 VKC 5 VJF. 6 VEE 7 VSC 8 VMP. 9 VGQ 10 VEE 11 VMT. 112 VLP. 13 K1T. 14 K1T. 102 XYN. 103 XSS 104 XTN. 105 XYN. 106 VHD 107 XSB	(K2B02 IP4853 (Q2306 (C0560 JF1158 EE1C95 SC5875 IP8764 308103 EE0286 MT0779 _P0123 ITZB9A00031 ITZB9A00052 (N26+A8FJK IN3+10JFJK (N26+J6FJ ID1774 SB3+8FJK	BOTTOM CASE U LENS CONNECTOR PLATE FOOT BASE U HINGE CLAMPER LENS CABLE MIC SHEILD CASE PB GUIDE ANGLE BOTTOM PB GUIDE 2 FRONT MIC CABLE GASKET FERRITE CORE COAXIAL CABLE (BLACK) COAXIAL CABLE (RED) SCREW SCREW SCREW SCREW SCREW SCREW	1 1 1 1 1 1 1 1 1 1 2 1 1						
2 VMP 3 VYQ 4 VKC 5 VJF 6 VEE 7 VSC 8 VMP 9 VGQ 10 VEE 11 VMT 112 VLP 13 K1T. 14 K1T. 102 XYN 103 XSS 104 XTN 105 XYN 106 VHD 107 XSB	MP4853 (702306	LENS CONNECTOR PLATE FOOT BASE U HINGE CLAMPER LENS CABLE MIC SHEILD CASE PB GUIDE ANGLE BOTTOM PB GUIDE 2 FRONT MIC CABLE GASKET FERRITE CORE COAXIAL CABLE (BLACK) COAXIAL CABLE (RED) SCREW SCREW SCREW SCREW SCREW SCREW	1 1 1 1 1 1 1 1 1 2 1 1	J0KG0000001					
2 VMP 3 VYQ 4 VKC 5 VJF 6 VEE 7 VSC 8 VMP 9 VGQ 10 VEE 11 VMT 112 VLP 13 K1T. 14 K1T. 102 XYN 103 XSS 104 XTN 105 XYN 106 VHD 107 XSB	MP4853 (702306	LENS CONNECTOR PLATE FOOT BASE U HINGE CLAMPER LENS CABLE MIC SHEILD CASE PB GUIDE ANGLE BOTTOM PB GUIDE 2 FRONT MIC CABLE GASKET FERRITE CORE COAXIAL CABLE (BLACK) COAXIAL CABLE (RED) SCREW SCREW SCREW SCREW SCREW SCREW	1 1 1 1 1 1 1 1 1 2 1 1	J0KG0000001					
3	(702306 (702306 (702560) JF1158 EE1C95 SC5875 JP8764 308103 EE0Z86 AT0779 JP0123 JTZB9A00031 JTZB9A00052 (7026+A8FJK SS3+8FJK TN3+10JFJK (7026+J6FJ JD1774 SB3+8FJK	FOOT BASE U HINGE CLAMPER LENS CABLE MIC SHEILD CASE PB GUIDE ANGLE BOTTOM PB GUIDE 2 FRONT MIC CABLE GASKET FERRITE CORE COAXIAL CABLE (BLACK) COAXIAL CABLE (RED) SCREW SCREW SCREW SCREW SCREW SCREW	1 1 1 1 1 1 1 1 2 1 1	J0KG0000001					
4 VKC 5 VJF 6 VEE 7 VSC 8 WWP 9 VGO 10 VEE 11 WIT 12 VLP 13 K1T 14 K1T 102 XYN 103 XSS 104 XTN 105 XYN 106 VHD 107 XSB	(CO560 JF1158	HINGE CLAMPER LENS CABLE MIC SHEILD CASE PB GUIDE ANGLE BOTTOM PB GUIDE 2 FRONT MIC CABLE GASKET FERRITE CORE COAXIAL CABLE (BLACK) COAXIAL CABLE (RED) SCREW SCREW SCREW SCREW SCREW SCREW SCREW	1 1 1 1 1 1 1 1 2 1 1 1	J0KG0000001					
5 VJF 6 VEE 7 VSC 8 VMP 9 VGQ 10 VEE 11 WMT 12 VLP 13 K1T. 14 K1T. 102 XYN 103 XSS 104 XTN 105 XYN 106 VHD 107 XSB	JF1158 EE1C95 SC5875 MP8764 G88103 EE0Z86 AT0779 P0123 ITZB9A00031 ITZB9A00052 (N26+A8FJK SS3+8FJK IN3+10JFJK (N26+J6FJ JD1774 SB3+8FJK	CLAMPER LENS CABLE MIC SHEILD CASE PB GUIDE ANGLE BOTTOM PB GUIDE 2 FRONT MIC CABLE GASKET FERRITE CORE COAXIAL CABLE (BLACK) COAXIAL CABLE (RED) SCREW SCREW SCREW SCREW SCREW SCREW SCREW	1 1 1 1 1 1 2 1 1 1	J0KG0000001					
6 VEE 7 VSC 8 VMP 9 VGQ 10 VEE 11 WIT1 12 VLP 13 K1T. 14 K1T. 102 XYN 103 XSS 104 XTN 105 XYN 106 VHD 107 XSB	EE1C95 SC5875 IP8764 S08103 EE0Z86 IT0779 P0123 ITZB9A00031 ITZB9A00052 ITZB9A00052 ITZB9A00052 ITZB9A00054 ITZB9A00054 ITZB9A00054 ITZB9A00054 ITZB9A00054 ITZB9A00054 ITZB9A00054 ITZB9A00055	LENS CABLE MIC SHEILD CASE PB GUIDE ANGLE BOTTOM PB GUIDE 2 FRONT MIC CABLE GASKET FERRITE CORE COAXIAL CABLE (BLACK) COAXIAL CABLE (RED) SCREW SCREW SCREW SCREW SCREW SCREW	1 1 1 1 2 1 1 1 2 4 4	J0KG00000001					
7 VSC 8 VMP 9 VGQ 10 VEE 11 VMT 12 VLP 13 K1T. 14 K1T. 102 XYN 103 XSS 104 XTN 105 XYN 106 VHD 107 XSB	CC5875 IP8764 308103 EE0Z86 IM70779 IP0123 ITZB9A00031 ITZB9A00052 ITZB9A10052 ITZB9A00052 ITZB9A00052 ITZB9A00052 ITZB9A00052 ITZB9A00052 ITZB9A00052	MIC SHEILD CASE PB GUIDE ANGLE BOTTOM PB GUIDE 2 FRONT MIC CABLE GASKET FERRITE CORE COAXIAL CABLE (BLACK) COAXIAL CABLE (RED) SCREW SCREW SCREW SCREW SCREW SCREW	1 1 1 2 1 1 1 2 4 4	J0KG0000001					
8 VMP 9 VGQ 10 VEE 11 VMT 11 VMT 11 12 VLP 13 K1T 14 K1T 14 K1T 102 XYN 103 XSS 104 XTN 105 XYN 106 VHD 107 XSB	MP8764 308103 EE0286 MT0779 P0123 ITZB9A00031 ITZB9A00052 (N26+A8FJK SS3+8FJK N3+10JFJK (N26+J6FJ HD1774 SB3+8FJK	PB GUIDE ANGLE BOTTOM PB GUIDE 2 FRONT MIC CABLE GASKET FERRITE CORE COAXIAL CABLE (BLACK) COAXIAL CABLE (RED) SCREW SCREW SCREW SCREW SCREW SCREW	1 1 2 1 1 1	J0KG0000001					
9 VGQ 10 VEE 11 VMT 12 VLP 13 K1T 14 K1T 102 XYN 103 XSS 104 XTN 105 XYN 106 VHD 107 XSB	308103 EE0286 AT0779 P0123 ITZB9A00031 ITZB9A00052 (N26+A8FJK SS3+8FJK N3+10JFJK (N26+J6FJ HD1774 SB3+8FJK	PB GUIDE 2 FRONT MIC CABLE GASKET FERRITE CORE COAXIAL CABLE (BLACK) COAXIAL CABLE (RED) SCREW SCREW SCREW SCREW SCREW SCREW SCREW	1 1 2 1 1 1 2 4	J0KG0000001					
10 VEE 11 WIT 12 VLP 13 K1T 14 K1T 102 XYN 103 XSS 104 XTN 105 XYN 106 VHD 107 XSB	EE0Z86 MT0779 P.P0123 ITZB9A00031 ITZB9A00052 (N26+A8FJK SS3+8FJK N3+10JFJK (N26+J6FJ ID1774 SB3+8FJK	FRONT MIC CABLE GASKET FERRITE CORE COAXIAL CABLE (BLACK) COAXIAL CABLE (RED) SCREW SCREW SCREW SCREW SCREW SCREW SCREW SCREW	1 2 1 1 2 2 4	J0KG0000001					
11 VMT1 12 VLP 13 K1T. 14 K1T. 102 XYN 103 XSS 104 XTN 105 XYN 106 VHD 107 XSB	MT0779 .P0123 .TZB9A00031 .TZB9A00052 .M26+A8FJK .SS3+8FJK .SS3+8FJK .M3+10JFJK .M26+J6FJ .HD1774 .SB3+8FJK	GASKET FERRITE CORE COAXIAL CABLE (BLACK) COAXIAL CABLE (RED) SCREW SCREW SCREW SCREW SCREW SCREW	2 1 1 2 2 4	J0KG0000001					
12 VLP1 13 K1T. 14 K1T. 102 XYN. 103 XSS 104 XTN. 105 XYN. 106 VHD 107 XSB.	P0123 ITZB9A00031 ITZB9A00052 (N26+A8FJK SS3+8FJK IN3+10JFJK (N26+J6FJ ID1774 SB3+8FJK	FERRITE CORE COAXIAL CABLE (BLACK) COAXIAL CABLE (RED) SCREW SCREW SCREW SCREW SCREW SCREW SCREW	1 1 2 4	J0KG00000001					
13 K1T. 14 K1T. 102 XYN 103 XSS 104 XTN 105 XYN 106 VHD 107 XSB	TZB9A00031 TZB9A00052 (N26+A8FJK SS3+8FJK FN3+10JFJK (N26+J6FJ HD1774 SB3+8FJK	COAXIAL CABLE (BLACK) COAXIAL CABLE (RED) SCREW SCREW SCREW SCREW SCREW SCREW	1 1 2 4					l	
14 K1T. 102 XYN 103 XSS 104 XTN 105 XYN 106 VHD 107 XSB	(N26+A8FJK SS3+8FJK FN3+10JFJK (N26+J6FJ HD1774 SB3+8FJK	COAXIAL CABLE (RED) SCREW SCREW SCREW SCREW SCREW SCREW	2						
102 XYN 103 XSS 104 XTN 105 XYN 106 VHD 107 XSB	(N26+A8FJK SS3+8FJK FN3+10JFJK (N26+J6FJ HD1774 SB3+8FJK	SCREW SCREW SCREW SCREW SCREW	4						
103 XSS 104 XTN 105 XYN 106 VHD 107 XSB	SS3+8FJK FN3+10JFJK (N26+J6FJ HD1774 SB3+8FJK	SCREW SCREW SCREW SCREW	4						
103 XSS. 104 XTN. 105 XYN. 106 VHD 107 XSB.	SS3+8FJK FN3+10JFJK (N26+J6FJ HD1774 SB3+8FJK	SCREW SCREW SCREW SCREW	4						
103 XSS 104 XTN 105 XYN 106 VHD 107 XSB	SS3+8FJK FN3+10JFJK (N26+J6FJ HD1774 SB3+8FJK	SCREW SCREW SCREW SCREW	4						
103 XSS 104 XTN 105 XYN 106 VHD 107 XSB	SS3+8FJK FN3+10JFJK (N26+J6FJ HD1774 SB3+8FJK	SCREW SCREW SCREW SCREW	4						
104 XTN. 105 XYN. 106 VHD 107 XSB.	FN3+10JFJK (N26+J6FJ HD1774 SB3+8FJK	SCREW SCREW SCREW							
105 XYN. 106 VHD 107 XSB. E16 VEP.	(N26+J6FJ HD1774 SB3+8FJK	SCREW SCREW							
106 VHD 107 XSB	HD1774 SB3+8FJK EP84406A	SCREW	11						
107 XSB	SB3+8FJK EP84406A		1						
E16 VEP	EP84406A		3						
E16 VEP:	EP84406A		Ť						
E16 VEP:	EP84406A								
E16 VEP.	P84406A								1
E17 VEP		REAR AUDIO P. C. BOARD	1						
	P80C55B	STEREO MIC P. C. BOARD	1						
			П						
			Н						
					 				
			H						
			H						
			H		 				
			H		 				
			H		 				
			H		l 				
								_	•

OVERALL SECTION (2)



			_				Ī	_	1
Ref. No.	Part No.	Part Name & Description	Pcs	Remarks	Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
			Ť					É	
	VMP8767	RECEIVER BOX	1					-	-
1									
2		RECEIVER COVER U	1						
3		RECEIVER CABLE	1						
4	VWJ16G8100L0	FFC	1						
5	VWJ40G7145L0	FFC	1						
6	VWJ30G7125L0		1						
7			1					-	-
	VEE0Z89	L SIDE CABLE	_						
8	VWJ40H2210L0		2						
9	VWJ30G6060L0	FFC	1						
10	VEE1A00	L SIDE LED CABLE	1						
▲ 11		USB CABLE	1						
<u> </u>	VEE1D52	USB WIRE CABLE U	1						
13	VGK3027	LAN CARD BASE	1						
14	VJF1535	COATING CLIP	2						
15	VJF1557	CLAMPER	1						
16	VWJ50G6060L0	FFC	1						
17	VGQ9384	CONDUCTIVE TAPE	1						
18	VYP9208	SIDE L U	1						
			_						
19	VMG1642	GUARD	1						
20	VMG1767	USB CAP	1			<u></u>		L	
21	VMG1768	BNC CAP(A)	1]	-		
22	VGB0677	P2HD BADGE	1						
23	VGB0625	PANA BADGE	1						
	VQL1N04	FCC/DOC LABEL	1		1	1			1
24								<u> </u>	
25	VYF3041	LAN COVER U TW	1					L	
	<u> </u>		L					L	
1									
101	XYN2+F6FJ	SCREW	3						
								-	-
102	XYN2+J6FJ	SCREW	6						
103	VHD1774	SCREW	1						
104	XSB3+4FJKT	SCREW	2						
105	XSB2+6FJK	SCREW	2						
106	XYN26+J6FJ	SCREW	14						
107	XSB3+16FJK	SCREW	2						
			_						
108	XYN3+J6FJ	SCREW	1						
109	VHD1462	SCREW	2						
E1	VEP81255A	CAMERA POWER P. C. BOARD	1						
	VEP23660A	CAMERA SYSCON P. C. BOARD	1					-	
E2			_						
E3	VEP23658A	CAMERA DSP 1 P. C. BOARD	1						
E4	VEP23659A	CAMERA DSP 2 P. C. BOARD	1						
E5	VEP83673A	SPD SYS MSC P.C.BOARD	1						
E6	VEP86359A	SPD CPU P. C. BOARD	1						
E7	VEP80C82A	SPD CARD 1 P. C. BOARD	2						
E8	VEP80C83C	SPD CARD 2 P. C. BOARD	1						
			H	FOR VERSOUSS				<u> </u>	
		SD CARD SUB P. C. BOARD		FOR VEP80V83C				_	
E9	VEP84400B	SPD AUDIO P.C.BOARD	1			<u></u>		L	<u> </u>
E10	VEP81254A	SPD POWER P. C. BOARD	1]	-		
E18	VEP80D81A	SPD P. C. BOARD	1					П	
E19		USB A CN P. C. BOARD	1					Т	
E21	VEP80E05A	L SIDE BNC P. C. BOARD	1						1
LZI	ACCOMECCA	L STUL DING P. G. DUAKU	Ľ		-			\vdash	
					-			_	
			Ш					L	
								Т	
 	1		-		-	1		Н	
								_	
			L						
	†							Н	
-	1		-		-			\vdash	
ļ	1		.		 	-		L	
ļ	<u> </u>					ļ			
	<u> </u>		L			<u> </u>		L	<u> </u>
1	1								
	1							H	
-	1		-		 			H	
	1		.		 	-		L	
ļ	<u> </u>					ļ			
			L					L	
	1					1			
—	1				—	 			1
		l							I


CAMERA PARTS ASSEMBLY(1)



CAMERA PARTS ASSEMBLY(1)

VE04539		1	AITTO AGGE		,	1		ese components, use only t		,
1 VEQ4540 CAMERA U 1 FOR AJ-HPX2100E/MC	Ref. No.	Part No.	Part Name & Description	Pcs	Remarks	Ref. No.	Part No.	Part Name & Description	Pes	Remarks
1 VEQ4540 CAMERA U 1 FOR AJ-HPX2100E/MC										
WIJ 1480965LD FRONT-PULSE FCC						 				
WPP675	1	VEQ4540	CAMERA U		FOR AJ-HPX2100E/MC	 				
WIJ1068037L1 SENSOR FFC 1			FRONT-PULSE FCC			 				
5 VSC5864 SHIELD CASE DRIVE 1 1			OPTICAL BLOCK ANGLE	1						
SCENERS SHIELD CASE PULSE 1			SENSOR FFC	1		 				
7			SHIELD CASE DRIVE	_		 				
S	6	VSC5865								
Section Sect			SHIELD CASE PREAMP							
9			FILTER KNOB (ND/CC)							
10			FILTER KNOB (ND)	_	FOR AJ-HPX2100E/MC					
11			CABLE U							
12			FILTER CABLE U	1						
13			FERRITE CORE	2						
14	12	VLP0123	FERRITE CORE	1	J0KG00000001					
15 VMT1815 GASKET 2 16 VMT1821 GASKET 1 17 VJF1158 CLAMPER 1 18 VGU0B22 FILTER KNOB (CC) 1 FOR AJ-HYPX2100E/MC 101 XQN2+B25FJ SCREW 2 107 XQN2+C4FJ SCREW 2 109 XXE26W3FP HEX SCREW 2 111 XYN26-J5FJ SCREW 22 111 XYN26-J5FJ SCREW 12 111 XYN26-J5FJ SCREW 1 1	13	VEE1C94		-1						
15 VMT1815 GASKET 2 16 VMT1821 GASKET 1 17 VJF1158 CLAMPER 1 18 VGU0B22 FILTER KNOB (CC) 1 FOR AJ-HYPX2100E/MC 101 XQN2+B25FJ SCREW 2 107 XQN2+C4FJ SCREW 2 109 XXE26W3FP HEX SCREW 2 111 XYN26-J5FJ SCREW 22 111 XYN26-J5FJ SCREW 12 111 XYN26-J5FJ SCREW 1 1	14	J0KD00000101	FERRITE CORE	1						
16 VMT1821 GASKET 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	15	VMT1815	GASKET	2						
17				1						
18				1						
101				1	FOR AJ-HYPX2100F/MC	1				
107	-			Ė		1			\vdash	
107						1	 			
107						1	†		H	<u> </u>
107	101	YON2+R2EE I	SCREW	2		1	 		\vdash	
109						1	1			
111	100	XXE36M3ED			E/MC: APCS	1	 		\vdash	
113 XYN3+J6FJ SCREW 1					L/ MIU · 4FU3	 	-		_	
E12 VEP23650A DRIVE P. C. BOARD 1 E13 VEP23653A PULSE P. C. BOARD 1										
E13 VEP23653A PULSE P. C. BOARD 1	113	X1N3+J0FJ	SCREW	- 1						
E13 VEP23653A PULSE P. C. BOARD 1										
E13 VEP23653A PULSE P. C. BOARD 1										
E13 VEP23653A PULSE P. C. BOARD 1										
E14 VP23652A PRE AMP P. C. BOARD 1				1						
	E14	VEP23652A	PRE AMP P. C. BOARD	1						
						1				
						1				
						1				
						-				
						1				
						 				
									L	
		<u> </u>					L			
						1				
						1	1			
						1	†		Т	
						1	†		Т	
						1	†		Н	
						1	†		Н	
						1	†		-	
						11	 		\vdash	
						 	-		_	
						 	 		_	
						 	1			1
						 	1			1
]			L	
		<u> </u>					L			
						11				
						11				
						11				
						1	†		-	
						11			-	
						1	1			
	ļ					 	-		-	<u> </u>


CAMERA PARTS ASSEMBLY(2)



CAMERA PARTS ASSEMBLY(2)

D. C. VI	D . V	D . M . A D	L	D 1	D. C. VI	D . M	D . M . O D	_	D 1
Ref. No.	Part No.	Part Name & Description	ıPcs	Remarks	Ref. No.	Part No.	Part Name & Description	Pes	Remarks
1	VYQ3933	OPTICAL U	1	FOR AJ-HPX2000P					
1	VYQ3863	OPTICAL U	1	FOR AJ-HPX2100E/MC					
2	VMAOT71	HEAT SINK (R)	1	TOTAL TOTAL TOTAL THE					
3	VMAOT72	HEAT SINK (G)	1						
4	VMAOT73	HEAT SINK B	1						
5	VMAOV41	HEAT SINK BASE	1						
6	VXQ1446	O. LPF U	1						
7 8	VDW1228 VDS0169	LENS MOUNT RING MOUNT CAP	1						
9	VEE2804	EARTH CABLE	2		-				
, , , , , , , , , , , , , , , , , , ,	VLLZOOT	EARTH GADEE	-						
101	XQN2+C4FJ	SCREW	3						
104	XYN3+C6FJ	SCREW	2						
105	XYN26+F6FJ XQS2+A4FJK	SCREW	6						
106 108	XSB3+6FJK	SCREW SCREW	3		-				
100	AODO : OF OR	OOKEN	H						
E11	VEP20B25C	CCD P. C. BOARD	1	•			-		
E15	VEP80D27A	POSITION SENSOR P. C. BOARD	1	FOR AJ-HPX2000P					
E15	VEP80D28A	POSITION SENSOR P. C. BOARD	1	FOR AJ-HPX2100E/MC					
		1	\vdash		 				
			\vdash						
			+						
			\Box						
			\vdash						
					-				
			\vdash						
			+						
			+						
			\Box						
			\Box						
			\sqcup						
			\sqcup		-				
			+						
			1 1						
			H						
				•			-		
			\sqcup						
			igdot						
			\sqcup						
			\vdash						
			+						
			+						
			$\dagger \dagger$						
				·			·		


CAMERA PARTS ASSEMBLY(3)




CAMERA PARTS ASSEMBLY(3)

	Τ	<u></u>	L			Π		L	
Ref. No.	Part No.	Part Name & Description	Pcs	Remarks	Ref. No.	Part No.	Part Name & Description	Pes	s Remarks
1	VYK1R08	FRONT CASE 1U	1						
2	VJF1256	CABLE CLAMPER	2						
3	VMG0948	EVF RUBBER SHIELD	1						
4	VMC1210	FRONT DOOR SPRING	1						
5	VMP4850	FRONT DOOR ANGLE	1						
6	VMS4088	FRONT DOOR ANGLE PIN	1						
7	VKF2485	FRONT DOOR	1						
8	VMG0832	SHIELD TUBE	1						
9	VXU1620	RUBBER BUTTON ASS'Y	1						
10	VGU9299	MENU BUTTON	1						
11	VGQ7131	BUTTON HOLDER PLATE	1						
12	VMT1432	WATERPROOF CUSHION	2						
13	VGU9861	MENU KNOB	1						
14	VMG1317	MENU WATERPROOF RUBBER	1						+
15	VMG1140	RAIN COVER SPONGE	2						
16	VEEOW38	MENU SW CABLE	1		-				1
10	VLLUNGO	MENO SW CADLE	-						-
									-
101	VVN0 - 0.45 1	CODEM	-		l 				
101	XYN2+C4FJ	SCREW	1		l 				
102	XSB2+4FJK	SCREW	2		l 				
103	XXEV2W4FP	SCREW	2		 				
105	XYN26+J6FJ	SCREW	3		 				
112	VMX1312	POLY WASHER	2		 				
									
E22	VEP80C57D	FRONT SW P. C. BOARD	1						
E23	VEP80C58C	MENU SW P. C. BOARD	1						
									+
									
					-				1
									-
					-				
					-				
			İ						
			İ						
	1								
	1								
									-
-									+
	1		-		 			-	
	1				l 				-
	1				l 				-
ļ					l 				<u> </u>
					l 				
					l 				
					l 				
			L					L	
			L					L	
									
L	1	1			·	ı		-	

TOP CASE & HANDLE PARTS ASSEMBLY




		W HANDLE I					ien replacin
No.	Part No.	Part Name & Description	Pcs	Remarks	Ref. No.	Part No.	
1	VYK2B03	TOP CASE U	1				ļ
2 3	VGM2190 VYQ3866	TOP CASE SLIDER U	1				1
4	VGH4698	VF LOCK NAME PLATE U	1	1SET			ļ
5	VGM2168	VF BASE	1				
6	VYQ4071	VF RING U	1				
7	VGU9854	SHAFT LOCK KNOB	2				
8	VLP0186	FERRITE CORE	1	J0KE00000027			
9	VJF1319	SH0E EVF CABLE	1				
10	VEE1C31 VEE0Z97	GPS WIRE U	1				
12	VLP0123	FERRITE CORE	1	J0KG00000001			
12	VEF1D45	OPERATE	1	001100000001			
14	VEE0Z91	HANDLE SW CABLE	1				
15	VSC5660	WL EARTH ANGLE	2				
16	VMT1631	VF CORE CUSION	1				
17	VYQ4070	FAN MOTOR U	1				
18	VMP8762	FAN COVER	1				
19	VSC5953	AD HEAT SINK	1				
20	VSC5954 VGQ9303	TOP HEAT SINK COOLING SHEET	1				
22	VJF1531	CABLE CLAMPER	2				
23	VYF3137	TOP COVER U	1				
24	VYH0375	HANDLE U	1				
25	VGL1113	TALLY COVER	1				
26	VGH4770	REC LABEL	1				
27	VMT1590	HANDLE SPONGE	1				
28	VGU9695	RUBBER BUTTON (B)	1				
29	VGU9214	SLIDE KNOB	1				
30	VMG1460	SLIDE SW RUBBER COVER	1				
31	VMG0955	P4 0-RING	1				
32	VMG0956 VKF3917	P8 O-RING HANDLE COVER	1				
34	VQL1D81	GPS LABEL	1				
04	VGLIDOI	UI O EADEE	<u> </u>				
36	VGQ8103	PB GUIDE 2	1				
37	VMP8763	PB GUIDE ANGLE TOP	1				
39	VGQ9355	COOLING SHEET	1				
40	VSC5966	EVF CABLE SHIELD ANGLE	1				
41	VMX3614	FAN SHEET	4				
	_						
	 				<u> </u>		
101	XVE4A25VW	HEX SCREW	2				
101	XXEV26W4FP	HEX SCREW	6				
102	XSS2+4FJK	SCREW	2				
104	VHD1793	HEX SCREW	3				
105	XWA3BFJK	WASHER	3				
106	XSN2+6FJK	SCREW	4				
107	XYN26+F6FJ	SCREW	2				
108	XYN2+F6FN	SCREW	5				
110	XSB4+8FJK	SCREW	2				
111	XSB3+8FJK	SCREW	14				1
112	XYN26+J6FJ	SCREW	16				
113	XSB2+6FJK XSB4+6FJK	SCREW SCREW	2				
114	A3D4+01JK	OUNEW	2		—		
E24	VEP80D06A	HANDLE SW P. C. BOARD	1				
E25	VEP80D07A	HANDLE TALLY P. C. BOARD	1				
E27	VEP80E06A	FAN CONNECT P. C. BOARD	1				
						_	
	<u> </u>						
	<u> </u>						
	 						
	 				-		+
	 						
			L				
	1				1		1



Ref. No.	Part No.	Part Name & Description	Pes	Remarks	Ref. No.	Part No.	Part Name & Description	Pc:	s Remarks
NO1. NO.	1410 110.	rare name a pescription	. 02	remat rs	E29	VEP80D82A	SPD SSW P. C. BOARD	1	- Molligi Ko
1	VYP9212	SIDE CASE R 2U	1	FOR AJ-HPX2000P	E30	VEP80D11A	POWER SW P. C. BOARD	1	
1		SIDE CASE R 2U		FOR AJ-HPX2100E/MC	E31	VEP80E07A	LCD OPEN SW P. C. BOARD	1	
2		SLIDE SW COVER	4	,	E32	VEP80D09A	TOGGLE P. C. BOARD	1	
3		FILTER NAME PLATE	1	FOR AJ-HPX2000P	E33	VEP80D03A	V MEM SW P. C. BOARD	1	
3		FILTER NAME PLATE	1	FOR AJ-HPX2100E/MC	E34	VEP80C64A	HEADPHONE P. C. BOARD	2	2
4	VGL1039	LED PANEL LIGHT	1	·	E35	VEP80D04A	SHOT M SW P. C. BOARD	1	
5	VGK3031	TOGGLE SW PLATE	1						
6		SLIDE SW ANGLE	1						
7		VR RAIN COVER PACKING	3		1				
8		SLIDE SW RUBBER	4						
9		BONDING TAPE A	1						
10		BONDING TAPE B	1						
11		LCD LOCK SHAFT	1						
12		MONITOR LOCK SPRING	1						+
13		OPERATION PANEL (B) U	1						+
14		MONITOR LOCK KNOB	1						
			·						
15		SLIDE PLATE SPRING	1						-
16		GUIDE PANEL	1						
17	VMG1286	CUSHION RUBBER	2						_
18		DOOR CUSHION	1						
19		MONITOR POP UP	1						
20		POP UP PLATE	1		L				
21		POP UP SPRING	1						
22		SPEAKER SET ANGLE	1						
23		VR KNOB FRONT	1						
24		VR KNOB	2					L	
25		OPERATION RUBBER BUTTON	_1					Ľ	
26	VGU8993	OPERATION BUTTON	1					Ľ	
27		WATERPROOF SW INSULATION SH	4		I -			Ι	
28	VGH4680	VR NAME PLATE	2						
29	VGH4948	VR NAME PLATE	1						
30	VMT1494	WATERPROOF CUSHION	4						
31		HEAD PHONE CABLE	1						
32		HP2 (REAR)	1						
33	VWJ30H2070L0		1						
34	VEE0Z93	TOGGLE CABLE	1						
35	VEE0Z96	SHOT M SW CABLE	2						
36	VEKOK89	SPEAKER U	1						
37		SPEAKER CUSHION	1						+
38		CLATCH SPACER	2						_
39		SPACER	1						_
40		COATING CLIP	1						
A 41		OPEN SW CABLE	1						
42		OPERATION DOOR U	1						
43		OPERATION BUTTON	1	lavaaaaaaa	1				
44		FERRITE CORE	2	J0KG00000001					
45		ANP BASE	1						
46		CLAMPER	1						
47		LED PANEL LIGHT	3					<u> </u>	
48	VMZ3692	LCD FFC SHEET	1						
49	VMT1801	FACE PAD	1						
50		CONDUCTIVE TAPE	1						
51	VMZ3685	LCD BARRIER A	1						
			L					L	
101	XTN3+6GFJ	SCREW	1					Ľ	
102	XYN2+J6FJ	SCREW	2					Ľ	
103	XYN2+F5FJ	SCREW	3						
104	XQN2+BJ4FJK	SCREW	1						
105		SCREW	2						
106	VMX1312	POLY WASHER	4					F	<u> </u>
107	XYN2+C5FJ	SCREW	2					F	<u> </u>
108		SCREW	19					<u> </u>	<u> </u>
109		SCREW	2					H	+
110		NUT	2					-	+
111		SCREW	1		—	1			+
			2		<u> </u>				
112		SCREW			-			H	+
113	XTB26+6GFJK	SCREW	8		ļ			-	-
114	XYN2+J6FJ	SCREW	5						
			_						
E28	VEP80E01A	SPD LCD P. C. BOARD	1						
_	<u> </u>		L		_	<u> </u>		L	<u> </u>
			ı —		1	1	<u></u>	1 -	1

CARD GUIDE PARTS ASSEMBLY


* The part number of card holder is written in Electric Parts List of each P.C.Board.



CARD GUIDE PARTS ASSEMBLY

Ref. No.	Part No.	Part Name & Description	Pos	Remarks	Ref. No.	Part No.	Part Name & Description	Pos	Remarks
Kel. No.	rart No.	rait Name & Description	I CS	Kellid1 KS	Kel. No.	rart NO.	rait Name & Description	LCS	Keliai KS
1	VGQ9272	CARD GUIDE	1						
2	VGH4773	CARD PLATE 1	1						
3	VMT1581	PB HOLD CUSHION (4)	4						
4	VSC5673	CARD EARTH ANGLE	1						
5	VSC5674 VSC5675	CARD GUIDE HEAT SINK 1 CARD GUIDE HEAT SINK 2	1						
7	VMT1628	CARD BRAKE PAD	1						
	VGH4802	CAD PLATE 2	1						
9	VSC5946	CCD SHIELD PLATE	1						
101	XYN2+F6FJ	SCREW	8						
102	XYN26+J6FJ	SCREW	8						
103	XYN2+J6FJ	SCREW	2						
E20	VEP80D10A	L SIDE LED P.C.BOARD	1						
								L	
								_	
					<u> </u>			-	
								-	
					—			\vdash	
					-			-	
					-				
					-				
					<u> </u>			-	
					-			-	
					—			\vdash	
					-			-	
								_	
								-	
								-	
								-	
								\vdash	
								Т	


REAR JACK PARTS ASSEMBLY



REAR JACK PARTS ASSEMBLY

		T .		[r	_	,
Ref. No.	Part No.	Part Name & Description	Pcs	Remarks	Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
1	VEJ2279	REAR JACK 1U	1						
2	VGU9300	SLIDE SW BUTTON	2						
3	VMG1511	RUBBER CAP C	1						
4	VMG1085	RAIN COVER RUBBER	2						
		RAIN COVER RUBBER							
5	VGL1038	BOTTOM TALLY COVER	1						
6	VEE1B06	CABLE	1						
7	VEE1C30	ECU CABLE U	1						
№ 8	VEE1C96	DC OUT CABLE U	1						
	K1SYYYYA0002	BNC CONNECTOR	1						
10	VEE1B45	1394 CABLE	1						
11	VJF1158	CLAMPER	1						
12	VMG1792	1394 CONNECTOR CAP	1						
13	VYK2B07	BOTTOM COVER U	1					f	
14	VMP8676	BACK LOCK ANGLE	1						
15	VMT1591	SHOULDER PAD	1						
16	VMG1508	RUBBER CAP	1						
17		XLR CONNECTOR CAP	1						
	VMG1636	ALK CUNNECTUR CAP							
18	VMG1769	AODIO OUT CONNECTER CAP	1		1				
1					ļ			<u> </u>	ļ
								<u> </u>	
L					<u> </u>				
		SCREW	4					Щ.	
102	XSN26+6FC	SCREW	4					L	
103	XSB2+6FJK	SCREW	2		1				
104	XSB3+6FJK	SCREW	8						
	1							t	
								H	
E37	VEP80C99C	REAR JACK P. C. BOARD	1					t	
E38		DC INPUT P. C. BOARD	1						
	VEP80D12H	1204 ON D. O. DOADD	1						
E39	VEP8UD12H	1394 CN P. C. BOARD	-						
								t	
ļ	1				1				
								<u> </u>	
								<u></u>	
								$oldsymbol{ol}}}}}}}}}}}}}}}}}}}}}$	
			L					L	
	1								
								t	
	†							H	
	†								
<u> </u>	 				1			┢	
<u> </u>	 				1			H	
-	 				<u> </u>			1	
ļ	1				1				
ļ	1				1				
			oxdot					Ш	
								L	
	1								
	†							H	
		l .					l	1	<u>. </u>


BACK CASE PARTS ASSEMBLY



BACK CASE PARTS ASSEMBLY


	ī	T	г	T			soo somponomo, ass smj	_	1
Ref. No.	Part No.	Part Name & Description	Pcs	Remarks	Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
1	VYK0Z63	BACK CASE U	1						
2	VJF1476	BATTERY ADAPTOR B	1						
3	VGF0960	CONNECTOR COVER	1						
4	VGF1058	BACK CASE COVER	1						
5	VMX2606	SPACER	2						
△ 6	VJF1347S	ANTON BRACKET	1						
7	VKC0601	HINGE (REAR)	1						
	VJF1498	TERMINAL HOLDER	1		=				
8	VJF 1498	TERMINAL HULDER							
9	VJR0696	CONNECTION TERMINAL	2						
10	VJF1158	CLAMPER	1						
	VHD1774	SCREW	1						
12	VGF1057	BACK BLIND SHEET	1						
13	VEUUR090ACF	CABLE	1						
14	VEUUB090ACF	CABLE	1						
15	VLP0123	FERRITE CORE	1	J0KG00000001					
16	VGQ1712	ANP BASE	1						
	VEE1C28	CABLE	1						
	VJF1535	COATING CLIP	1						
10	VOI 1000	OUATTING GETT	<u>'</u>						-
 			-		—			-	
-			<u> </u>		-			<u> </u>	
	vouse er ::	a a D F W	!					-	
101	XSN26+6FJK	SCREW	2					<u> </u>	
102	XSB3+4FJK	SCREW	2						
103	XSB3+6FJK	SCREW	2					L	
104	VMX2605	WASHER	2					L	
105	XYN26+J6FJ	SCREW	2					1	
			Ī						
			l					Ī	
	1		t					t	
E26	VEP80D89B	INTERFACE P. C. BOARD	1						
E20	VEROUDOSD	INTERFACE P. C. DUARD	- 1		=				
			-						
			ļ		-				
			ļ						
			1		-				
			<u> </u>						
			-						
			<u> </u>						
			-						
			ļ		-				
			İ						
			Ī					1	
			t						
			 					<u> </u>	
			t						
	1		1		-				
 			┢		—			\vdash	
-			1		 			-	
-			<u> </u>		-			<u> </u>	
			-						
			<u> </u>						
			L^{T}					L^{T}	
			Ì						
			Ī						
			t						
	1		t					t	
			t					H	
-			H					\vdash	
 			-		—			\vdash	
			1						
			<u> </u>		ļ				
			<u> </u>					<u> </u>	
1	1		1					1	
			Ì						
			t					Ī	
			t					H	
		I		I .				_	<u>, </u>

LCD PARTS ASSEMBLY



LCD PARTS ASSEMBLY

Ref. No.	Part No.	Part Name & Description	Pcs	Remarks	Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
							^		
2	VYK2B05 VGQ8616	LCD U HINGE COVER (LOWER)	1						
3	VGQ8775	HINGE COVER (TOP)	1						
4	VXD0465	HINGE	1						
5	VMG1286	CUSHION RUBBER UPPER LCD COVER	1						
6 7	VKW3338 VGP6152	LCD CASE BOTTOM	1						
8	VMT1717	WATERPROOF PAD	1						
9	VMZ3610	LCD PCB INSULATION SHEET	1						
101	XQN16+B4FJK	SCREW	6						
E36	VEP08346A	LCD LEV P. C. BOARD	1						
			-					-	
					-				
			-					-	
					-			\vdash	
					-				
								-	
			-					-	



PACKING PARTS ASSEMBLY

		I .			·				
Ref. No.	Part No.	Part Name & Description	Pcs	Remarks	Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
1	VFC4148	SHOULDER BELT	1						
2	VFB0203	CAMERA ACCESSORY U	1						
▲ 3	VQT1D27	OPERATING INSTRUCTIONS		AJ-HPX2000P					
▲ 3	VQT1D31	OPERATING INSTRUCTIONS		FOR AJ-HPX2100E					
∆ 3	VQT1D29	OPERATING INSTRUCTIONS		FOR AJ-HPX2100MC					
<u> </u>	VYQ3979	OPERATING INSTRUCTIONS	1						
△ 4	VYQ4038	OPERATING INSTRUCTIONS	1	FOR AJ-HPX2100MC					
5	VPG1L01	PACKING CASE		AJ-HPX2000P					
	VPGILUI	PACKING CASE	1	AJ-HPX2000P					
5	VPG0T77	PACKING CASE		FOR AJ-HPX2100E/MC					
6	VYQ4015	CUSHION U (TOP)	1						
7	VYQ4016	CUSHION U (LOWER)	1						
8	VPF1176	POLYETHYLENE BAG	1						
9	VPK2280	ACCESSORY BOX (A)	1						
10	VPK2298	ACCESSORY BOX B	1						
11	VQL1K06	PACKING LABEL	2	FOR AJ-HPX2100E					
11	VQL1K05	PACKING LABEL	2	FOR AJ-HPX2100MC					
12	VPN1791	PAD		FOR AJ-HPX2100MC					
13	VPG1D41	PACKING CASE		FOR AJ-HPX2100MC					
	 								
1	1				}			-	
—								-	
	-							-	
-	.								
	 							-	
								-	
	ļ								
	 				1			\vdash	
	-							-	
	1							<u> </u>	
	 								
								-	
	_							<u> </u>	
								_	
	1								
								L	
								H	
	†							-	
	 				1			\vdash	
	 							-	
	1							 	
1	1							-	
	_							<u> </u>	
								_	
	ļ								
			╚					_	
	1		<u> </u>					 	
	1	1						_	